


DESKRITE 100

Small

Installation Guide



CAUTION

Please read all instructions carefully before using this product.

Retain this manual for future reference.

The specifications of this product may vary slightly from the illustrations and are subject to change without notice.


Accessory Package List



Note: The drawings below are for reference only and may differ slightly.
Any items missing or installation problems, please contact customer service.



x1



x1



x1



x1



x2




x8



x4


Technical Data




CAUTION

Please do not exceed the maximum weight bearing.

Assembly step 1



Using two people, carefully remove the DeskRite 100 Platform from the packaging.
Carefully place onto the desk/table surface.




CAUTION

Please place the DeskRite 100 platform onto a suitably sized desk/table surface.

Assembly step 2

Grip the adjusting handles and workstation top to adjust the surface up to a suitable height to begin assembly step 3.




CAUTION

Please do not put fingers/hands near supporting bars.


Assembly step 3

- a. Attach covers to connecting arms.
- b. Connect and fix the junction plates to the keyboard tray by using the 8 screws supplied.
- c. Hang the junction plate on the knob assembly and then tighten all of the knobs.
Make sure all four points on the plate are attached securely.



Assembly step 4


Carefully place devices onto the top of the DeskRite 100 workstation platform.



CAUTION

Caution. Make sure the devices do not overhang the sides, back, or front of the platform surface. Make sure that the total weight of the products does not exceed the recommended maximum weight (see page 2).

Assembly step 5




CAUTION

Adhesive buckle helps keep the cables tidy and clean. Please leave enough length of cable for the height adjustment function.

Caution



Please make sure that all installed equipment is on the platform surface and is not protruding over the edge of the desk.



Adhesive buckle helps to keep the cables tidy. Please leave enough length of cable for height adjustment function.



Please first adjust it to the highest setting, then remove equipment to avoid harm or damage.



Use two people to move DeskRite 100 platform.



WARNING

Hand pinching.
Please do not put hands or fingers near the supporting bars.