

# POSITIV PLUS

## Setup Instructions




### 1. Seat Height

Raise lever (1) to raise or lower height of seat.




### 2. Locking mechanism

To release chair into free-float mode, raise lever (2) and lean back slightly. To lock into your current position, push down lever (2). The free-float mechanism needs to be balanced to the individual user using lever (4).



### 3. Back Angle

Raise lever (3) and hold to set back angle independently to seat pan. Let go of lever to lock your sitting angle.




### 4. Body Weight Tension

Wind hand-wheel (4) anti-clockwise (backwards) to loosen and clockwise (forwards) to tighten.



### 5. Seat Slide

Pull out lever (5) and wind hand-wheel clockwise (forwards) to slide seat forward or anti-clockwise (backwards) to slide back.



### 6. Back Height

In seated position, use your right hand to lift lever (6) up and slide the backrest to the desired height. Let go to lock into position.



### 7. Inflatable Lumbar

Lumbar pump is situated at the back of the chair. Push pump to increase air into the backrest. Push small valve situated to the side of the pump to decrease air.



### 8. Adjustable Armrests (optional)

Adjustable in 3-dimensions. Height: lift lever on outside of armrests, slide up and down. Depth: push in button on the inside of arm tops, slide them back and forwards. Width: undo butterfly clips at base of arms, slide in and out.



### 9. Neckrest (optional)

Adjustable in 2-dimensions. Height: slide neckrest up and down. Depth: tilt angle of headrest back and forwards.

[posturite.co.uk](http://posturite.co.uk)